



Power tiller

DF 12SL/DF 15SL/DF 18SL/DF 20SL/DF 22SL

DONGFENG Brand power tiller/Two-wheel tractor is of dual-function type that can be used as a means of traction as well as drive. It is featured by its simple and compact structure, good reliability, long service life, easy operation, ample output, light weight and good cross-country ability. It is powerful and efficient. It is very suitable for use in paddy fields, dry fields, orchards, vegetable gardens and hilly land with a little inclination. It can be used for ploughing, rototilling, harrowing in paddy fields, harvesting, drilling, ditching, transportation and etc. if suitable farm implements or accessories are attached. In addition, it can also be extensively used as a stationary power source for small scale drainage and irrigation, sprinkling, grain threshing, cotton ginning, flour milling, fodder cutting and so on.

Model of Power Tiller	DF-12SL	DF-15SL	DF-18SL	DF 22SL
Structure weight (kg)	455	465	495	540
Turning speed of rotatilling shaft (rpm)	188/300			
Number of blades (PCS)	18 (option: 20,24,28)			
Rototiling width (mm)	600 (option: 800,900, 1200)			
Gearbox	6F+ 2R			
Tire size	6.00-12			
Wheel track (mm)	800, 740, 640			
Min. ground clearance (mm)	185			
Model of engine	ZS195N	ZS1100N	ZS1105N	ZS1115N
Type of engine	Single-cylinder, Horizontal, 4-stroke, Direct injection, Water cooling			
Bore × stroke (mm)	95×115	100×115	105×115	115×115
Turing speed of crankshaft (rpm)	2200			
Power (hp)	12	15	18	22
Cooling mode	Condenser (Radiator)			